DATA USER'S HANDBOOK

INTRODUCTION

The formats for the various data products are described below:

1. The Sensor Data Record (SDR) provides time tagged altimeter and radiometer data.
2. The Navy Geophysical Data Record (NGDR) appends earth location and geophysical corrections to the SDR data.
3. The NOAA Geophysical Data Record (GDR) provides an archived data set on CD ROM, updated as improved orbits and geophysical corrections become available.
4. The Cal/Val Formats provides the actual formats used in the calibration and validation (Cal/Val) effort.

These data sets combined are provide the information produced by GFO continuously during the mission:

1. Earth located measurement data.
2. Payload data during Calibration and Acquisition mode.
3. Payload engineering data.
4. Waveform data records during calibration mode and acquisition mode.
5. Payload operations data including the payload command log, spacecraft significant event log, and any changes in the Center of Gravity or payload configuration.
6. Waveform data over Greenland.

This handbook provides the information necessary to access and use the data:

DATA PRODUCTION

The GFO spacecraft memory is dumped several times per day to the ground system Remote Sites. Two raw telemetry data files are constructed at the remote sites containing 1) altimeter and radiometer science data and 2) altimeter and radiometer engineering data. These files are transferred to the POC where they are maintained on-line for 7 days. Data from the GPS receiver and Doppler Beacon are transmitted to the SOC from the remote sites. Operational and Precision orbits are computed at the SOC and transmitted to the POC.

The GFO payload data is sent from the Remote Site to the POC in a POC data file, one data file per DSU dump. The POC decommutates the data contained in the POC data file and processes the data into the SDR File. The Sensor Data Record produced from each data dump includes data only when the altimeter is in Fine Track Mode. Once the SDR has been produced, the original payload data arrays are scanned and the four files (ASCII) created. There is one file each for the altimeter data, altimeter calibration containing all full waveform data, water vapor radiometer data and the ancillary engineering data. The engineering data is a subset of the full ancillary data set and contains only the information required to produce an SDR. In the event there is no data, a message stating "No data available" is output to the file. Engineering unit conversions (using the coefficients found in the Command & Telemetry Manual) and VTCW to UTC are the only operations done on the payload data before being written to the Cal/Val Files. Gaps in the data are not zero filled in the Cal/Val Files.

The ADFC transfers the SDR (by FTP) to the CalVal server along with the corresponding ASCII files.

SDR FORMAT, CONTENTS, AND ALGORITHMS

This section provides an SDR Data Format Table that lists each parameter in the SDR, an SDR Parameter Table that defines each parameter, an SDR Algorithm Table that describes the algorithm used to produce each parameter, and tables of the Altimeter Constants and the Radiometer Algorithm and Constants.

[--- return to the Data Handbook ---](#)

1.0 SDR Data Format Table

Each SDR includes a header and multiple data records.

The file name has the form: "sdryyddd_hh_mm_ss_xxxxx.dat" where xxxxx = number_of_records.

The first line in the file is ASCII text.

The Header includes an ASCII string (42 bytes long) followed by a binary portion (744 bytes long).

Each binary Data Record is 256 bytes long. Two Quality Words define the status of the data. The two RA Status words and known flag problems are described under the Altimeter File Description

---

1.1 SDR Data Record Format

The Gate Index contains the gate index of all ten RA frames. The index is 3 bits in length with the first frame's index starting at bit 0 (rightmost), 2nd frame starting bit position 3, etc.

Item	Parameter	Units	Bytes/Type	Limits/Range
1	Frame UTC	Seconds	8 - Dbl	0-86400.0
2	RA Status Mode I	Bit Pattern	2 - Int	N/A
3	RA Status Mode II	Bit Pattern	2 - Int	N/A
4	RA Quality Test Results	Bit Pattern	4 - Int	N/A
5	WVR Quality Test Results	Bit Pattern	4 - Int	N/A
6	Gate Index	Bit Pattern	4 - Uns Int	N/A
7	H(1)	mm	8 - Dbl	TBD
8	H(2)	mm	8 - Dbl	TBD
..	..	..	..	…
16	H(10)	mm	8 - Dbl	TBD
17	H_Rate	m/sec	4 - Flt	TBD
18	Height Word STD	mm	4 - Flt	TBD
19	FM Crosstalk	mm	4 - Flt	TBD
20	SWH(1)	m	4 - Flt	0-20
21	SWH(2)	m	4 - Flt	0-20
..	..	..	..	….
29	SWH(10)	m	4 - Flt	0-20
30	SWH STD	m	4 - Flt	TBD
31	SWH Bias (Off-nadir, SWH)	m	4 - Flt	TBD

32	AGC(1)	dB	4 - Flt	0-64
33	AGC(2)	dB	4 - Flt	0-64
..	..	..	..	….
41	AGC(10)	dB	4 - Flt	0-64
42	AGC STD	dB	4 - Flt	0-64
43	AGC Temperature Correction	dB	4 - Flt	TBD
44	Delta AGC Height	dB	4 - Flt	TBD
45	AGC Correction for Attitude	dB	4 - Flt	TBD
46	Attitude Wave Height Bias	mm	4 - Flt	TBD
47	Off-nadir Angle	deg	4 - Flt	0-5
48	Backscatter Coefficient	dB	4 - Flt	TBD
49	Path Delay	cm	4 - Flt	TBD
50	22 GHz Brightness Temp	K	4 - Flt	TBD
51	37 GHz Brightness Temp	K	4 - Flt	TBD
52	Average VATT	volt	4 - Flt	0-2
53	Fitted VATT	volt	4 - Flt	0-2
54	Receiver Temperature	deg C	4 - Flt	TBD

Return to the beginning

1.2 Quality Word Format

Quality Word #1

Data Element Identifier (bit)	Data Description	Type	Units of Measure	Limits/ Range	Size (bits)
31-MSB	RA data frame 1 missing	int	N/A	0,1	1
30	RA data frame 2 missing	int	N/A	0,1	1
29	RA data frame 3 missing	int	N/A	0,1	1
28	RA data frame 4 missing	int	N/A	0,1	1
27	RA data frame 5 missing	int	N/A	0,1	1
26	RA data frame 6 missing	int	N/A	0,1	1
25	RA data frame 7 missing	int	N/A	0,1	1
24	RA data frame 8 missing	int	N/A	0,1	1
23	RA data frame 9 missing	int	N/A	0,1	1
22	RA data frame 10 missing	int	N/A	0,1	1
21	height STD error	int	N/A	0,1	1
20	AGC STD error	int	N/A	0,1	1
19	SWH STD error	int	N/A	0,1	1
18	off nadir error	int	N/A	0,1	1
17	trs 1 temperature error	int	N/A	0,1	1
16	trs 2 temperature error	int	N/A	0,1	1
15	rcvr 1 temperature error	int	N/A	0,1	1
14	rcvr 2 temperature error	int	N/A	0,1	1

13	dfb temperature error	int	N/A	0,1	1
12	hgt bounds error	int	N/A	0,1	1
11	AGC bounds error	int	N/A	0,1	1
10	SWH bounds error	int	N/A	0,1	1
9	rate error	int	N/A	0,1	1
8	spare	int	N/A	0	1
7	no smoothed VATT	int	N/A	0,1	1
6	VATT estimate error	int	N/A	0,1	1
5	rcvr temperature error	int	N/A	0,1	1
4	backscatter error	int	N/A	0,1	1
3	RA not in fine track	int	N/A	0,1	1
2	record is zero filled	int	N/A	0,1	1
1	spare	int	N/A	0	1
0-LSB	spare	int	N/A	0	1

Quality Word #2

Note: A value of 1 in bit 31 signifies either a configuration change, the RA is not in the fine track mode, or an error has occurred.

Data Element Identifier	Data Description	Type	Units of Measure	Limits/ Range	Size (bits)
31-MSB	RA configuration changed	int	N/A	0,1	1
30	0 - RA #1; 1 - RA #2	int	N/A	0,1	1
29	0 - SSPA #1; 1 - SSPA #2	int	N/A	0,1	1
28	spare	int	N/A	0	1
27	spare	int	N/A	0	1
26	spare	int	N/A	0	1
25	spare	int	N/A	0	1
24	spare	int	N/A	0	1
23	spare	int	N/A	0	1
22	spare	int	N/A	0	1
21	spare	int	N/A	0	1
20	spare	int	N/A	0	1
19	spare	int	N/A	0	1
18	spare	int	N/A	0	1
17	spare	int	N/A	0	1
16	spare	int	N/A	0	1
15	22 GHz temp out of bounds	int	N/A	0,1	1
14	37 GHz temp out of bounds	int	N/A	0,1	1
13	possible rain	int	N/A	0,1	1
12	probable rain	int	N/A	0,1	1
11	land contamination	int	N/A	0,1	1
10	sun glint	int	N/A	0,1	1
9	WVR latch up	int	N/A	0,1	1
8	WVR interpolated	int	N/A	0,1	1

7	WVR data missing	int	N/A	0,1	1
6	spare	int	N/A	0	1
5	spare	int	N/A	0	1
4	spare	int	N/A	0	1
3	spare	int	N/A	0	1
2	spare	int	N/A	0	1
1	spare	int	N/A	0	1
0-LSB	spare	int	N/A	0	1

Return to the **beginning**

1.3 SDR Header Format

The Generic File Header is a '\n' terminated ASCII string. All fields after the Generic File Header are binary.
Note: Item 2 (Filename) appears in the form "sdryydddhhmmssxxxxx.dat" where xxxxx = number_of_records.

Item	Parameter	Units	Bytes/Type	Limits/Range
1	Generic File Header	N/A	42 - Char[]	N/A
2	Filename	Filename	40 - Char[]	Legal UNIX name
3	Number of SDR Records	Record number	4 - Int	0-62449
4	Start Time Year (time of 1st RA data sample)	Year	4 - Int	00-99
5	Start Time Day of Year (time of 1st RA data sample)	Day of Year	4 - Int	1-366
6	Start Time Hour (time of 1st RA data sample)	Hour	4 - Int	0-23
7	Start Time Minutes (time of 1st RA data sample)	Minutes	4 - Int	0-59
8	Start Time Seconds (time of 1st RA data sample)	Seconds	4 - Int	0-59
9	SDR Start UTC	Seconds	8-Dbl	0-86400.0
10	SDR Stop UTC	Seconds	8 - Dbl	0-86400.0
11	Number of CAL Mode Ops	N/A	4 - Int	0-15
12	Height Calibration Bias	mm	4 - Flt	0.0
13	AGC Calibration Bias	dB	4 - Flt	0.0
14	Waveform Sampler Gate Calibration (1-64)	0.0001 (no units)	256 - Flt	0-2
15	Waveform sampler Gate Calibration from Cal Table (1-64)	0.0001 (no units)	256 - Flt	0-2
16	Altitude Bias (initial)	km	4 - Flt	E3
17	Altitude Bias based on S/C CG	mm	4 - Flt	0-10E4
18	Time Bias (Initial)	Seconds	4 - Flt	+/-0.1
19	AGC Bias (Initial)	dB	4 - Flt	TBD
20	UTC Year (scc file time for VTCW to UTC conversion)	years	4 - Int	00-99

21	UTC Day (scc file time for VTCW to UTC conversion)	days	4 - Int	1-366
22	PAD	N/A	4 - Char	N/A
23	UTC Seconds (scc file time for VTCW to UTC conversion)	seconds	8 - Dbl	0-86400.0
24	VTCW Value	ticks	8 - Dbl	N/A
25	Ratio	sec per VTCW tick	8 - Dbl	N/A
26	Velocity of Light	m/sec	8- Dbl	2.99792458E8
27	AGC Limit Upper Bound	dB	4 - Flt	0-64
28	AGC Limit Lower Bound	dB	4 - Flt	0-64
29	H Limit Upper Bound	km	4 - Flt	825.0
30	H Limit Lower Bound	km	4 - Flt	775.0
31	Hgt Rate Limit	m/sec	4-Flt	40.0
32	Off- Nadir Upper Bound	deg	4 - Flt	0-0.8
33	SWH Limit Upper Bound	m	4 - Flt	0-20
34	SWH Limit Lower Bound	m	4 - Flt	0-20
35	Rcvr Temp Upper Bound	deg C	4 - Flt	50.0
36	Rcvr Temp Lower Bound	deg C	4 - Flt	10.0
37	Rad Temp 22 GHz Lower Limit	K	2 - Int	105 (TOPEX)
38	Rad Temp 22 GHz Upper Limit	K	2 - Int	240 (TOPEX)
39	Rad Temp 37 GHz Lower Limit	K	2 - Int	130 (TOPEX)
40	Rad Temp 37 GHz Upper Limit	K	2 - Int	260 (TOPEX)
41	Possible Rain Lower Limit (37 GHz)	K	2 - Int	200 (TOPEX)
42	Possible Rain Upper Limit (37 GHz)	K	2 - Int	230 (TOPEX)
43	Probable Rain Limits (37 GHz) Lower Limit	K	2 - Int	230 (TOPEX)
44	Probable Rain Limits (37 GHz) Upper Limit	K	2 - Int	260 (TOPEX)
45	Land Contamination - Lower Limit	K	2 - Int	260
46	Sun Glint - Lower Limit	K	2 - Int	300
47	AGC STD Reason Limit	dB	4 - Flt	TBD
48	Height Word STD Reason Limit	mm	4 - Flt	TBD
49	Height Rate STD Reason Limit	m/sec	4 - Flt	TBD
50	SWH STD Reason Limit	m	4 - Flt	TBD
51	Rcvr Cal Temp	deg C	4- Flt	TBD

Return to the beginning

2.0 SDR Parameter Definition Table

Item	Parameter	Definition

2	RA Status Mode I	See RA Status Mode I Table.
3	RA Stat. Mode II	See RA Status Mode II Table.
4	Quality Word I	See Quality Word I Table.
5	Quality Word II	See Quality Word II Table.
6	Gate Index	The Gate Index contains the gate index of all 10 RA frames
7 - 16	H(1) - H(10)	Sea surface height determined on-board the spacecraft at a 10 per second rate (no corrections).
17	H_Rate	Height rate averaged at 1 per second rate (no corrections).
18	Height Word STD	Standard deviation from a linear fit to the 10 per second sea height values. Only non-rejected values are used with a minimum of 6 points required.
19	FM Crosstalk	The computed FM Crosstalk correction for the height data - see the CalValDR Algorithm Table.
20-29	SWH(1)-SWH(10)	Significant Wave Height determined on board the spacecraft at a 10 per second rate (no corrections).
30	SWH STD	Standard deviation of the 10 per second SWH values.
31	SWH Bias	The computed attitude/SWH correction for the SWH - see the CalValDR Algoritm Table.
32-41	AGC(1) - AGC(10)	Automatic Gain Control determined on board the spacecraft at a 10 per second rate.
42	AGC STD	Standard deviation of the 10 per second automatic gain control values. Only non-rejected values with a minimum of 6 good points required.
43	AGC Temperature Correction	The measured temperature of the altimeter receiver is used to derive this correction to the AGC for receiver gain changes.
44	Delta AGC Height	Computed delta height correction for the AGC - see the CalValDR Algorithm Table.
45	AGC Correction for Attitude	Computed correction for the AGC to account for satellite off nadir angle. - see the CalValDR Algorithm Table.
46	Attitude Wave Height Bias	The computed correction for the height to correct for the attitude/SWH effect. - see the CalValDR Algorithm Table.
47	Off-nadir Angle	The altimeter's determination of satellite off nadir angle based on VATT. - see the CalValDR Algorithm Table.
48	Backscatter Coefficient	Backscatter coefficient computed from AGC, applying corrections for satellite height, receiver temperature, attitude/SWH effect, onboard calibration, and prelaunch calibration. - see the CalValDR Algorithm Table.
49	Path Delay	Altimeter path delay as determined by the Water Vapor Radiometer using Ruf's Algorithm. - see the CalValDR Algorithm Table.
50	22 GHz Brightness Temperature	Brightness temperature as measured by the Water Vapor Radiometer (no corrections).
51	37 GHz Brightness Temperature	Brightness temperature as determined by the Water Vapor Radiometer (no corrections).
52	Average VATT	Voltage proportional to ATTitude - see the CalValDR Algorithm Table.
53	Fitted VATT	Fit to the VATT - see the SDR Algorithm Table and the CAL/VAL/QC Plan.
54	Receiver Temperature	The measured receiver temperature that is used to correct the AGC value.

Return to the **beginning**

3.0 SDR Algorithm Table

This table describes the processing algorithms that have been applied to produce the corrections in the SDR data fields. The Calibration Constants

(constants listed in each algorithm) are in ASCII files external to the SDR program. The files are included here after this table. The Cal/Val/QC Plan describes the updating of the Calibration Constants based on prelaunch and on-orbit data. The limits are included here after the constants table.

D0054.009[02A]CEC

Algorithm	Definition
Algo 1: Fitted VATT	The altimeter H, SWH, and AGC measurements must be corrected to account for the impact of spacecraft attitude control error. The spacecraft off-nadir attitude excursions cause the slope of the plateau region of the return waveform to decrease. The altimeter detects this change in slope and generates a parameter named Voltage proportional to ATTitude (VATT) that is the primary input to these corrections. The altimeter outputs raw VATT samples at a 10.2 Hz rate. This algorithm averages and then edits the values and then performs a first order polynomial fit to provide a smooth VATT sample at a nominal 1 Hz rate (0.98 sec interval) for later corrections.
Step 1 - VATT	If the altimeter data frame is GOOD, the 10 10/sec VATT samples are averaged to produce one VATT[i] for the ith data frame. The resulting Average VATT is in the SDR

Average	record produced.
Step 2 - Gate Index Correction	The VATT[i] is next normalized to account for the gate index in use. The equation is: VATT[i] = a0[gate_index] + a1[gate_index]*VATT[i]. The normalized VATT[i] is not in the SDR.
Step 3 - VATT[i] Rate (Magnitude) Test	The difference between the current and proceeding VATT[i] is formed and if the magnitude exceeds a preset threshold, the current sample is not passed to the fit routine. This test discards samples caused by land, rain cells, etc. that cause an abrupt change in the waveform. The threshold is ra_limits.thr(0).
Step 4 - Nominal Range Test	A test is now applied to reject all VATT[i] samples that do not fall within a nominal range (ra_limits.vatt_low to ra_limits.vatt_high. Samples that fall below the lower limit are indicative of a specular or near specular ocean return.
Step 5 - Height Rate Test	A test is now applied to reject VATT[i] samples when the measured height rate is below a threshold (ra_limits.hgt_rate_limit, indicating that the measurement is unreliable due to lack of digital filter bank averaging. (NOT DONE ON GFO)
Step 6 - Track Mask Test	A test is now applied to reject VATT[i] samples when the altimeter mode does not satisfy "fine track" criterion (320 MHz chirp, low variability, track algo, AGC from AGC gate, EML height error not exceeded, precision EML tracking). These masks are hard wired in the code. If the mode does not satisfy the mask, all records are zero filled. (NOT DONE ON GFO)
Step 7 - Least Squares Fit	A first order polynomial fit routine (from the GEOSAT ICD) is now applied to the sample points that remain in order to determine Fitted_VATT[i] for each 1 sec data frame. The fitted VATT is written to the SDR record produced. The fit routine operates on a sliding 1 minute data span. The nominal case is to estimate a central value from data over +/- 30 seconds (62 VATT[i] values). Points that deviate from the linear fit by more than 3 times the standard deviation about the fit are rejected and the remaining points are fitted again. If the number of points falls below the prescribed count (15), but above 4, the fit is used and a quality flag is set. If the number of points to fit falls below 4, the fit is not used and an extrapolation using the most recent fit constants is performed.
.	.
Algo 2: Off-Nadir Angle	The Fitted_VATT[i] is used to estimate the satellite off-nadir angle at a 1 per second rate using the algorithm: off_nadir_angle[i]= b1*SQRT(Fitted_VATT[i] - b0). The resulting off nadir angle is in the CalValDR produced. The constants are ra_constants.b0 and ra_constants.b1. If noise causes the argument of the SQRT to be negative, the off nadir angle for that frame is set to zero.
.	.
Algo 3: SWH bias (Correction for Attitude, SWH)	The Fitted_VATT[i] is used to derive a one per second satellite off-nadir angle correction to the altimeter SWH measurement. The algorithm for the SWH correction is given by: SWH_bias_attitude= K[gate_index]*(Fitted_VATT[i] - b0). The resulting SWH bias correction is in the CalValDR produced. The constants are ra_constants.b0 and ra_constants.k[gate_index]. If (Fitted_VATT[i] - b0) = 0, then SWH_bias_attitude=0.
.	.
Algo 4: Height Correction for Attitude and Sea State (Attitude Waveht Bias)	The Fitted_VATT[i] and SWH are used to derive a one per second correction to the altimeter height measurement. The algorithm for the Height correction is given by: H_bias= c0[gate_index][Corrected_SWH] +Fitted_VATT[i]*c1[gate_index][Corrected_SWH]. The resulting H bias correction is in the CalValDR produced. The Corrected_SWH is determined from the SWH by first averaging the 10 10/sec SWH values and then correcting the ave_SWH by the SWH_bias from step 3 above.
.	.
Algo 5: AGC Correction for Attitude and Sea State	The Fitted_VATT[i] and SWH are used to derive a one per second correction to the altimeter SWH measurement. The algorithm for the Height correction is given by: AGC_bias= d0[gate_index][Corrected_SWH] +Fitted_VATT[i]*d1[gate_index][Corrected_SWH] The resulting AGC bias correction is in the CalValDR produced.
.	.

SDR FORMAT, CONTENTS, AND ALGORITHMS

Algo 6: Height Correction for FM Crosstalk	A one second average of the altimeter 10/sec height rate measurements is used to derive a correction to the height measurement for the range/Doppler crosstalk effect of linear FM waveforms. The algorithm for the height correction is given by the equation: H_crosstalk_bias= (46.9/107.4)*ave_height_rate. The resulting H_crosstalk_ bias correction is in the SDR record produced.
.	.
Algo 7: AGC Correction for Height Variation (Delta AGC Height)	A one second average of the altimeter 10/sec height measurements is used to derive a correction to the AGC for the variation in height. The algorithm for the correction is given by: AGC_height_bias= 30 log (ave_height/initial_height). The resulting AGC_height_ bias correction is in the SDR record produced.
.	.
Algo 8: AGC Correction for Receiver Temp	The measured temperature of the altimeter receiver is used to derive a correction to the AGC for receiver gain changes. The algorithm for the correction is given by: AGC_temperature_correction= k_t0+(k_t1*Rcvr_T)+(k_t2*Rcvr_T**2). The resulting correction: AGC Temperature_Correction is in the SDR record produced. The default receiver temperature is defined in the ra_constants table.
.	.
Algo 9: AGC Calibration Lookup	A long term AGC drift correction, AGC_cal_bias, is derived by off-line analysis of altimeter calibrate mode data. The correction is included in the SDR header.
.	.
Algo 10: AGC Initial Offset	An initial offset is selected during ground testing to convert AGC measurements to backscatter coefficient measurements. The correction is included in the SDR header.
.	.
Algo 11: ave_AGC	A frame of 10 10/sec AGC values is averaged to produce ave_AGC at a one per second rate.
.	.
Algo 12: Backscattr Coefficient	The backscatter coefficient is computed using the algorithm: Backscatter coefficient= ave_AGC - AGC_cal_bias + AGC_temperature_correction + AGC_height_bias + AGC_attitude_bias - AGC_initial_offset and written into the CalValDR produced.

Return to the beginning

3.1 Altimeter Constants

Note that there are 4 different altimeter configurations: ra1/sspa1, ra1/sspa2, ra2/sspa1, and ra2/sspa2. The pre-launch constants for all four configurations are set as noted in the table below.

		SDR Correction Constants					
Gate Index	H-1/3 Range	c0	c1	d0	d1	a0	a1
1	<.625	10.45463	-6.45929	-6.94208	6.33180		
1	.625 to .9375	11.00605	-6.80099	-6.95484	6.34192	-0.00076	1.00043
1	>.9375	11.85432	-7.31417	-6.94917	6.33611		
2	<1.79688	13.42933	-8.31773	-6.92383	6.32317		

2	1.79688 to 2.42188	16.33199	-10.11647	-6.91872	6.31642	-0.00596	1.00333
2	>2.42188	19.62077	-12.17858	-6.93596	6.32775		
3	<4.21875	27.17765	-16.94702	-6.85119	6.27887		
3	4.21875 to 5.39063	32.68521	-20.48797	-6.86089	6.28241	-0.02259	1.01274
3	>5.39063	38.76554	-24.40598	-6.88596	6.29777		
4	<8.98438	51.40449	-32.83095	-6.67721	6.17054		
4	8.98438 to 11.5625	64.14288	-41.48602	-6.71310	6.18890	-0.06190	1.03602
4	>11.5625	77.35845	-50.72013	-6.75978	6.21537		
5	<17.10938	97.06467	-66.76093	-6.45979	6.01777		
5	>=17.10938	113.59410	-79.80987	-6.50140	6.03712	-0.12730	1.07908

b0 = 1.1419
b1 = 0.8747

number_VATT_pt = 62
good_pt_thres = 62
min_VATT_samples = 30

h_initial = -0.019893 mm

AGC_initial = ~~33.0 dB~~   *31.86 dB*   *This parameter changed 25 Feb 00*

k = { 0.0 0.0 0.0 0.0 0.0}

default_recv_temp = 30.0

g0 = 46.38069
g1 = 107.4

trs_1_coeff = 0.2
trs_2_coeff = 0.2

recv1_coeff = 0.2
recv2_coeff = 0.2

dfb_coeff = 0.2

recv_1 k_t0 = ~~3.6191~~ *-5.5301*   *Note: These parameters were changed on 25 Feb 00*
recv_1 k_t1 = ~~-0.0865~~ *0.1323*   *for both pdp_ra1_ssp a1 and pdp_ra1_ssp a2*
recv_1 k_t2 = ~~0.0~~   *0.0*

recv_1 cal_temp = 41.8

recv_2 k_t0 = 1.8282
recv_2 k_t1 = -0.0436
recv_2 k_t2 = 0.0

recv_2 cal_temp = 41.9

Altimeter limits table --

Note: The format of the data is very critical. There must be a space between each label or number.

For example:

pd_a0 = 123.45 is correct pd_a0=123.4 is incorrect and will be ignored

Document Last Changed: June 12, 1998, Changed by: Ball

agc_upper_bound = 64.0
agc_lower_bound = 0.1

hgt_upper_bound = 825.0 km
hgt_lower_bound = 775.0 km

off_nadir_upper_bound = 0.8

swh_lower_bound = 0.01 m
swh_upper_bound = 20.00 m

rcvr_temp_upper_bound = 50.0
rcvr_temp_lower_bound = 10.0

vatt_low = 1.0
vatt_high = 2.2

agc_reason = 10.0

hgt_word_reason = 50.0
hgt_rate_reason = 200.0

swh_reason = 5.0

rcv_cal_temp = 20.0

trs_1_low_limit = 10.0
trs_1_high_limit = 50.0
trs_2_low_limit = 10.0
trs_2_high_limit = 50.0

recv_temp_1_low_limit = 10.0
recv_temp_1_high_limit = 50.0
recv_temp_2_low_limit = 10.0
recv_temp_2_high_limit = 50.0

dfb_temp_low_limit = 10.0
dfb_temp_high_limit = 50.0

thr0 = 0.15

hgt_rate_limit = 40.0

range_correct_low = { 0.62500 1.79688 4.21875 8.98438 17.10938 }
range_correct_high = { 0.93750 2.42188 5.39063 11.5625 17.10938 }

bck_scat_low = 7.0
bck_scat_high = 14.0

Return to the beginning

3.2 Radiometer Algorithm and Constants

GEOSAT Follow-On Water Vapor Radiometer
Path Delay Retrieval Algorithm

Christopher S. Ruf
The Pennsylvania State University
Version 16 May 1995

BACKGROUND:

The wet tropospheric path delay correction to the altimeter range measurement (henceforth referred to as the path delay) can be expressed to first order as a linear combination of the WVR brightness temperatures

(1) $\quad\quad$ PD = c0_global + c1_global*TB22 + c2_global*TB37

where PD is the path delay and TBff is the brightness temperature at frequency ff. The retrieval coefficients ci,global are found by regression analysis using a large set of radiosonde profiles of the atmosphere. The residual error in this regression fit is improved by stratifying the database into subsets of the path delay and the cloud liquid water content. The cloud liquid water content, LIQ, is also estimated by a linear combination of TBs

(2) $\quad\quad$ LIQ = c0_liq + c1_liq*TB22 + c2_liq*TB37

where the retrieval coefficients ci,liq are found by regression analysis of a large ensemble of radiosonde profiles, similar to the above coefficients. The retrieval coefficients can be expanded into sub-groups appropriate for different ranges of the path delay and liquid. The stratified path delay retrieval then becomes

(3) $\quad\quad$ PD2 = c0(PD,LIQ) + c1(PD,LIQ)*TB22 + c2(PD,LIQ)*TB37

where PD is a first guess at the path delay (made by using (1) with coefficients ci_global derived from a global distribution of path delays), LIQ is the liquid water estimate made using (2), and the coefficients ci(j,k) are derived from appropriate subsets of distributions of the path delay and liquid water content. The residual error in this stratified regression fit can be further improved slightly, and the dependence of the bias in the fit on ocean surface wind speed can be reduced significantly, by removing the windspeed dependent bias

(4) $\quad\quad$ PD3 = PD2 + ëPD(WS)

where ëPD is a tabulated list of PD bias corrections vs. windspeed, WS. WS is determined from å0, the normalized radar cross section measured by the radar altimeter via a look-up table.

SOFTWARE IMPLEMENTATION:

A number of tables of retrieval coefficients are needed in order to implement this algorithm. The values for ci_global and ci_liq and for ci(j,k) are given below. The index i = 0,1,2 represents the offset, TB22, and TB37 coefficients, respectively. The index j = 1,2,3,4 represents the path delay stratification, where

j = 1 $\quad\quad$ for 0 <= PD < 10 cm
j = 2 $\quad\quad$ for 10 <= PD < 20 cm
j = 3 $\quad\quad$ for 20 <= PD < 30 cm
j = 4 $\quad\quad$ for 30 <= PD cm

and the index k = 1 or 2 represents the liquid stratification, where

k = 1 $\quad\quad$ for 0 <= LIQ < 100 microns (i.e. clear skies)
k = 2 $\quad\quad$ for 100 <= LIQ microns (i.e. cloudy skies)

A table of windspeed dependent path delay bias corrections, ëPD in (4), is also given below. This table has 7 entries, for the windspeed ranges

1 $\quad\quad$ for 0 <= WS < 7 m/s
2 $\quad\quad$ for 7 <= WS < 10 m/s
3 $\quad\quad$ for 10 <= WS < 13 m/s
4 $\quad\quad$ for 13 <= WS < 16 m/s

5	for $16 <= WS < 19$ m/s
6	for $19 <= WS < 22$ m/s
7	for $22 <= WS$

Finally, a look-up table relating altimeter å0 to WS is provided. This table is extracted from Witter and Chelton, J. Geophys. Res., 96, 8853-8860, 1991. In using this look-up table, extrapolation beyond the values listed for å0 is as follows: for å0>19.6 dB assume WS=0 and for å0<7.0 dB assume WS>=22 m/s. Weighted averaging of the path delay will be used to smooth the behavior of PD2 at the transition points in the stratification with respect to path delay. No weighted averaging is used for the cloud liquid stratification or for the windspeed dependent bias correction. Let PD be the value retrieved by (1) and LIQ be the value retrieved by (2). There are two different cases to consider in the weighted average. If either PD >= 35 cm or PD < 5 cm, then the value for PD2 given by (3) is exact. Otherwise, define PDL as the odd multiple of 5 below or equal to PD and PDU as (PDL + 10). A weighted average of the PD2 values returned by (3) using the PDL and the PDU stratification levels is used, as defined by

(5) $PD2 = PD2L + ((PD2U-PD2L)/10)*(PD - PDL)$

where PD2L = PD2(PDL,LIQ) and PD2U = PD2(PDU,LIQ). Finally, the windspeed dependent bias correction is made, according to (4), and PD3 is the final path delay correction.

TABLES:

The following tables list the values needed to implement this algorithm.

RESIDUAL ERROR ANALYSIS:

The quality of fit between this PD retrieval and the true PD is determined using an ensemble of 29,172 radiosonde atmospheric profiles from 28 open ocean launch sites distributed over the globe during 1992-1994. The RMS difference between the retrieved and true PD, assuming no noise in the TBs or in å0, is 0.64 cm. This is the intrinsic error in the algorithm. The RMS error, assuming realistic errors of +/-1.0 K in the TBs and +/-0.5 dB in å0, is 0.77 cm.

GFO WVR WET PATH DELAY RETRIEVAL ALGORITHM COEFFICIENTS:

Table 1. Global and stratified PD and Liquid from TB

Bin	c0	c1	c2
_global	-43.513	0.422	-0.090
_liq	-2271.387	-5.980	20.831
0<=PD<10; LIQ<100	-25.939	0.281	-0.059
10<=PD<20; LIQ<100	-53.544	0.321	0.082
20<=PD<30; LIQ<100	-63.882	0.381	0.081
30<=PD; LIQ<100	-49.351	0.226	0.193
0<=PD<10; LIQ>=100	-12.147	0.246	-0.111
10<=PD<20; LIQ>=100	-32.252	0.413	-0.151
20<=PD<30; LIQ>=100	-47.306	0.474	-0.128
30<=PD; LIQ>=100	-43.773	0.443	-0.106

Table 2. Wind speed dependent wet path delay retrieval bias corrections

Bin (m/s)	0-7	7-10	10-13	13-16	16-19	19-22	>22
Bias (cm)	0.22850	0.03592	-0.38714	-0.81554	-1.18394	-1.35222	-2.07217

Table 3. Modified Chelton-Wentz altimeter RCS vs. wind

		windspeed

sig0 (dB)	(m/s)
7.0	21.373
7.2	20.781
7.4	20.189
7.6	19.579
7.8	18.958
8.0	18.321
8.2	17.662
8.4	16.979
8.6	16.276
8.8	15.555
9.0	14.821
9.2	14.075
9.4	13.316
9.6	12.545
9.8	11.763
10.0	10.970
10.2	10.169
10.4	9.361
10.6	8.546
10.8	7.739
11.0	6.975
11.2	6.279
11.4	5.642
11.6	5.051
11.8	4.509
12.0	4.021
12.2	3.582
12.4	3.196
12.6	2.871
12.8	2.595
13.0	2.342
13.2	2.113
13.4	1.927
13.6	1.777
13.8	1.641
14.0	1.505
14.2	1.370
14.4	1.238
14.6	1.120
14.8	1.031
15.0	0.970
15.2	0.925
15.4	0.883

15.6	0.842
15.8	0.800
16.0	0.759
16.2	0.718
16.4	0.676
16.6	0.635
16.8	0.593
17.0	0.552
17.2	0.510
17.4	0.469
17.6	0.427
17.8	0.385
18.0	0.344
18.2	0.302
18.4	0.261
18.6	0.219
18.8	0.177
19.0	0.136
19.2	0.094
19.4	0.053
19.6	0.012

Return to the [beginning](#)

(Status 29 May 1998)

CALVAL FORMAT, CONTENTS, AND ALGORITHMS

There is a Cal/Val File for the altimeter data (Altimeter File), for the altimeter calibration containing all full waveform data Calibration File), for the water vapor radiometer data (Radiometer File) and one for the ancillary engineering data (Engineering File). The engineering data is a subset of the full ancillary data set and contains only the information required to produce an SDR. In the event there is no data, a message stating "No data available" is output to the file. Engineering unit conversions (using the coefficients found in the Command & Telemetry Manual) and VTCW to UTC are the only operations done on the payload data before being written to the Cal/Val Files. Gaps in the data are not zero filled in the Cal/Val Files.

--- return to the CalVal Data Handbook ---

1.0 ALTIMETER FILE DESCRIPTION

The RA Data Record Format Table - Short Telemetry Frame describes the raw RA data produced while the RA is in the Track1, Track2 or Standby mode. The RA Data File Format Table - Short Frame shows the format of the ASCII representation of the RA data in the RA data file. Bit pattern values are presented as a hex value. Multiple values on one line are delimited by spaces. Each individual RA frame is delimited by a blank line. The RA data filename is: "ra_datayyddd_hh_mm_ss.dat" which corresponds to the SDR produced using the data. A description of the Altimeter problems and work arounds is provided

1.1 RA Data Record Format Table - Short Frame

Item	Parameter	Units	Bytes/Type	Source
1	Frame Sync	0xF9AF	Unsigned Int	RA
2	RA Status Mode I	Bit Pattern (See Note 1)	2 - Unsigned Int	RA
3	RA Status Mode II	Bit Pattern (See Note 1)	2 - Unsigned Int	RA
4	Height	mm	Double	POC
5	Height Rate	m/sec	Float	POC
6	Height Error	meters	Float	POC
7	AGC	dB	Float	POC
8	Gate Index Change Flag	Bit Pattern	Unsigned Int	RA
9	Gate Index	Bit Pattern	Unsigned Int	RA
10	VATT	N/A	Float	POC
11	SWH	meters	Float	POC
12	Co-Latitude	degrees	Float (0-180)	POC
13	UTC	seconds	Double	POC

Note 1: The RA Status Mode Descriptions are contained in the RA Status Mode I & II Tables.

1.2 RA Data File Format Table - Short Frame

<Frame Number:>

<F9AF>

<Status Mode I> <Status Mode II>

<Height>

<Height Rate>

<Height Error>

<AGC>

<Gate Index Change Flag> <Gate Index>

<VATT>

<SWH>

<Co-Latitude>

<UTC>

1.3 Description of Altimeter problems

Integration testing of the RA indicated an incorrect response of the RA telemetry word RASTBY. Subsequent testing identified three other telemetry responses which did not appear nominal. Three of the anonmalous responses are defined below, along with suggested work arounds. The fourth anonmalous response does not impact the altimeter calibration effort.

1. RASTBY - this flag should indicate whether the altimeter is actively performing measurements. Should indicate "Active" in all Track and Calibrate modes. Should indicate "Standby" in Standby and Memory Dump modes. What it does: Upon initial power-up, the altimeter correctly indicates "Standby". Commands to Track or Calibrate modes then also correctly indicate "Active". Once the "Active" indication is achieved, it will not change. Subsequent changes in the altimeter operation back to the Standby mode will not result in a "Standby" indication.
   Work around: While in "Standby", the altimeter continues to output whatever data is in the output buffer. The RA data frames may be analyzed for uniformity of data. If x number of frames are equal, then it may be possible to assume the altimeter is in "Standby". Once the frames are different, the altimeter is in the "Active" mode.

2. RATEST - this flag indicates whether the altimeter is in a Test Mode or if a Built-In-Test (BIT) error has occurred. Due to several patches being installed in the altimeter, this flag always indicates a BIT failure.
   Work around: Ignore this flag.

3. RATRACKP - this flag should indicate which tracker parameters are being used. A "Normal" should indicate the tracker is using a fixed set of tracking parameters. This is the condition for Track 1 Mode. A "Custom" should indicate the tracker is using a set of ground selectable tracking parameters. This is the condition for Track 2 Mode. What it does: the flag always indicates "Normal", regardless of which set of tracking parameters are being used.
   Work around: The custom parameters are available in the status 2 word, bits 0 - 2.

Return to the beginning

2.0 Calibration File Description

The RA Data Record Format Table - Long Telemetry Frame describes the raw RA data produced while the RA is in the Cal I, Cal II or Track3 mode. The RA Data File Format Table - Long Frame shows the format of the ASCII representation of the RA data in the RA data file. Bit pattern and scaled count values are presented as an hex value. Multiple values on one line are delimited by spaces. Each individual RA frame is delimited by a blank line.

The RA data filename for the calibration data is: "ra_calyyddd_hh_mm_ss.dat". Descriptions of the two RA Status Modes are provided.

2.1 RA Data Record Format Table - Long Frame

Item	Parameter	Units	Bytes/Type	Source
1	Frame Sync	0xF9AF	Unsigned Int	RA
2	RA Status Mode I	Bit Pattern (See Note 1)	2 - Unsigned Int	RA
3	RA Status Mode II	Bit Pattern (See Note 1)	2 - Unsigned Int	RA
4	Height	mm	Double	POC
5	Height Rate	m/sec	Float	POC
6	Height Error	microsec	Float	POC
7	AGC	dB	Float	POC

8	Gate Index Change Flag	Bit Pattern	Unsigned Int	RA
9	Gate Index	Bit Pattern	Unsigned Int	RA
10	VATT	N/A	Float	POC
11	SWH	meters	Float	POC
12	AGC Gate Amplitude *	Scaled Counts	Unsigned Int	RA
13	Early Gate Amplitude *	Scaled Counts	Unsigned Int	RA
14	Late Gate Amplitude *	Scaled Counts	Unsigned Int	RA
15	Middle Gate Amplitude *	Scaled Counts	Unsigned Int	RA
16	L-E Binary Count *	Scaled Counts	Unsigned Int	RA
17	Attitude Gate Amplitude *	Scaled Counts	Unsigned Int	RA
18	Noise Gate Amplitude *	Scaled Counts	Unsigned Int	RA
19	Waveform Data *	Scaled Counts	64 samples, 8 bits each (unsigned)	RA
20	Waveform Scaling Factor	Numeric	Unsigned Int	RA
21	Co-Latitude	degrees	Float (0-180)	POC
22	UTC	seconds	Double	POC

Note 1: The RA Status Mode Descriptions are contained in the RA Status Mode I & II Tables.

Note 2: Fields marked with a "*" need to have the following operation performed on them:
Original DFB counts = Scaled Counts * (Waveform Scaling Factor + 1)

2.2 RA Data File Format Table - Long Frame

```
<Frame Number:>
<F9AF>
<Status Mode I> <Status Mode II>
<Height>
<Height Rate>
<Height Error>
<AGC>
<Gate Index Change Flag> <Gate Index>
<VATT>
<SWH>
<AGC Gate Amplitude> <Early Gate Amplitude> <Late Gate Amplitude> <Middle Gate Amplitude>
<L-E Binary Count> <Attitude Gate Amplitude> <Noise Gate Amplitude>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA> <WV_DATA>
<Waveform Scaling Factor>
<Co-Latitude>
<UTC>
```

Note 1: The RA Status Mode Descriptions are contained in the RA Status Mode I & II Tables.

2.3 RA Status Modes

RA Status Mode I
Status Mode II contents:

Bit 15 MSB	0 = Last Command Received 1 = Status (See Descriptions)
Bit 14 Bit 13 Bit 12	Telemetry Format: 000 = Normal Short (Standby, Track 1 & 2) 001 = Coarse Long (Track 3, C. Acq, C. Trk) 010 = Fine Long (Track 3, Fine Acq, Fine Trk) 011 = Calibrate I (Cal I, Test 3) 100 = Calibrate II (Cal II, Test 3,4,8) 101 = Memory Dump 110 = Uplink Dump (Track 3 or Cal) 111 = Debug (Track 3 or Cal)
Bit 11	Standby/Active: 0 = Standby 1 = Active
Bit 10	Bandwidth: 0 = 5 MHz 1 = 320 MHZ
Bit 9	Variability: 0 = Low Variability 1 = High Variability
Bit 8	BIT/Test Summary: 0 = Normal Operation 1 = BIT Failure or Test Mode in use (These are detailed in Status Mode II)
First Minor Frame Status	
Bit 7	Acquisition/Track: 0 = Acquisition Algorithm 1 = Track Algorithm
Bit 6	AGC Source: 0 = AGC from SMAX 1 = AGC from AGC gate
Bit 5	EML Height Error Limit: 0 = Limit Exceeded 1 = Within Bounds
Bit 4	Precision EML Tracking: 0 = Threshold Tracking 1 = Precision EML Tracking
Second Minor Frame Status	
Bit 3	Acquisition/Track: 0 = Acquisition Algorithm 1 = Track Algorithm
Bit 2	AGC Source: 0 = AGC from SMAX 1 = AGC from AGC gate
Bit 1	EML Height Error Limit: 0 = Limit Exceeded 1 = Within Bounds
Bit 0 LSB	Precision EML Tracking: 0 = Threshold Tracking 1 = Precision EML Tracking

Status Mode II Field Descriptions	
Bit 15 MSB Bit 14 Bit 13	Word Type: 000 = Track 2 Parameters Word 0 001 = Track 2 Parameters Word 1 010 = Track 2 Parameters Word 2 011 = Track 2 Parameters Word 3 100 = Track 2 Parameters Word 4 101 = Configuration 110 = Bit
Bits 12-0 LSB	Word Type Dependent

Status Mode II Configuration Field Description	
Bit 15 MSB Bit 14 Bit 13	101
Bit 12	Tracker Parameters Select 0 = Normal (Track Mode 1) 1 = Custom (Track Mode 2)
Bit 11 Bit 10	Height Error Constraint 00 = Normal 01 = Threshold only (Test Mode 5) 10 = Gate only (Test Mode 6)
Bit 9 Bit 8	Tracker Constraint 00 = Normal 01 = Coarse only (Test Mode 11) 10 = Coarse to Fine only (Test Mode 2)
Bit 7	Tracker Freeze Flag 0 = Normal 1 = Freeze (Test Mode 9)
Bit 6	Gate Index Freeze Flag 0 = Normal 1 = Freeze (Test Mode 7)
Bit 5 Bit 4	Calibration Constraint 00 = Normal 01 = Freeze State (Test Mode 3) 10 = RFI Scan (Test Mode 4) 11 = High AGC Search (Test Mode 8)
Bit 3	1 = No Watchdog Reset (Test Mode 12)
Bit 2	Uplink Pending 0 = Uplink Buffer Empty 1 = Uplink Buffer not Empty
Bit 1	1 = 5 MHZ Test Mode Active (Test Mode 1)
Bit 0 - LSB	1 = 320 MHZ Test Active (Test Mode 10)

Return to the beginning

3.0 Radiometer File Description

The raw WVR data format is shown in the WVR Data Format table. The WVR temperatures are converted from raw counts to ASCII hex notation and placed in the WVR Data File. The power supply and Rad Data values are not converted and are written as hex values. Each item represents 0.5

seconds. A space delimits each value and a blank line delimits each frame.

The filename for the WVR data file is: "wvr_datayyddd_hh_mm_ss.dat" which corresponds to the SDR produced using the data.

3.1 WVR Data Format

Item					
1	Frame Sync (E25C)	22 Feed Temp	22 Feed Ther Blk Temp	22 Ch Rad Data P/R	37 Ch Rad Data P/R
2	37 Feed Temp	37 Feed Ther Blk Temp	P.S. +28V	22 Ch Rad Data P/R	37 Ch Rad Data P/R
3	22 Feed WG Temp	37 Feed WG Temp	P.S. +5V	22 Ch Rad Data P/R	37 Ch Rad Data P/R
4	Temp Calib 1	Temp Calib 2	P.S. +12V	22 Ch Rad Data P/R	37 Ch Rad Data P/R
5	22 Horn Temp	22 Horn Ther Blk Temp	P.S. -12V	22 Ch Rad Data P/R	37 Ch Rad Data P/R
6	37 Horn Temp	37 Horn Ther Blk Temp	P.S. +15V	22 Ch Rad Data P/R	37 Ch Rad Data P/R
7	22 Ant WG Input Temp	37 Ant WG Input Temp	P.S. -15V	Cold Load Calib	Cold Load Calib
8	Temp Calib 3	Temp Calib 4	22 Ch AGC V P/R Status - 1	22 Ch Rad Data P/R	37 Ch Rad Data P/R
9	22 Horn WG Input Temp	37 Horn WG Input Temp	37 Ch AGC V P/R Status - 2	22 Ch Rad Data P/R	37 Ch Rad Data P/R
10	22 Ch WM Load Temp	37 Ch WM Load Temp	22 Ch P/R Status - 3	22 Ch Rad Data P/R	37 Ch Rad Data P/R
11	22 Ch Mxr WG Temp	37 Ch Mxr WG Temp	37 Ch P/R Status - 4	22 Ch Rad Data P/R	37 Ch Rad Data P/R
12	Temp Calib 5	Temp Calib 6	22/37 Ch OP Mode N/C Status - 5	22 Ch Rad Data P/R	37 Ch Rad Data P/R
13	Spare	Spare	Cal Mode WM/Cold Status - 6	22 Ch Rad Data P/R	37 Ch Rad Data P/R
14	Spare	Tx Blank	Latchup	22 Ghz Warm Sky Calib	37 Ghz Warm Sky Calib

Note: 1) WVR Status 3, 4, 5: 0 = fault, 1 = OK; and, 2) Latchup: 0 = Latchup, 1 = OK

3.2 WVR Data File Format

The WVR data is placed in the WVR Data File in the following format:

```
<Frame Number:>
<Frame Sync> <22 Feed Temp> <22 Feed Ther Blk Temp> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<37 Feed Temp> <37 Feed Ther Blk Temp> <P.S. +28V> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<22 Feed WG Temp> <37 Feed WG Temp> <P.S. +5V> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<Temp Calib 1> <Temp Calib 2> <P.S. +12V> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<22 Horn Temp> <22 Horn Ther Blk Temp> < P.S. -12V> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<37 Horn Temp> <37 Horn Ther Blk Temp> < P.S. +15V> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<22 Ant WG Input Temp> <37 Ant WG Input Temp> < P.S. -15V> < Cold Load Calib> < Cold Load Calib>
<Temp Calib 3> <Temp Calib 4> <22 Ch AGC V P/R Status - 1> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
```

<22 Horn WG Input Temp> <37 Horn WG Input Temp> <37 Ch AGC V P/R Status-2> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<22 Ch WM Load Temp> <37 Ch WM Load Temp> <22 Ch P/R Status-3> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<22 Ch Mxr WG Temp> <37 Ch Mxr WG Temp> <37 Ch P/R Status-4> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<Temp Calib 5> <Temp Calib 6> <22/37 Ch OP Mode N/C Status-5> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<Spare> <Spare> <Cal Mode WM/Cold Status-6> <22 Ch Rad Data P/R> <37 Ch Rad Data P/R>
<Spare> <Tx Blank> <Latchup> <22 Ghz Warm Sky Calib> <37 Ghz Warm Sky Calib>
<Co-Latitude>
<UTC>

Return to the [beginning](#)

4.0 Engineering File Description

The [Payload Engineering data](#) is converted to engineering units and written to the [Engineering Data file](#) in ASCII. Character fields are delimited by a space.
The filename is: "eng_datayyddd_hh_mm_ss.dat".

4.1 Payload Engineering Data Format

Item	Parameter	Units	Bytes/Type	Source
1	Frame Sync	0xAEFF	Unsigned Int	S/C
2	RA Config	0 = RA 1 SSPA 1 1 = RA 1 SSPA 2 2 = RA 2 SSPA 1 3 = RA 2 SSPA 2	Unsigned Int	S/C
3	WVR Config	0 = WVR 1 1 = WVR 2	Unsigned Int	S/C
4	Composite Receiver Temp	deg C	Float	Note 1
5	RA 1 Receiver Temp	deg C	Float	RA 1
6	RA 1 TRS 1 Temp	deg C	Float	RA 1
7	RA 1 TRS 2 Temp	deg C	Float	RA 1
8	RA 1 Receiver 1 Temp	deg C	Float	RA 1
9	RA 1 Receiver 2 Temp	deg C	Float	RA 1
10	RA 1 DFB Temp	deg C	Float	RA 1
11	RA 2 Receiver Temp	deg C	Float	RA 2
12	RA 2 TRS 1 Temp	deg C	Float	RA 2
13	RA 2 TRS 2 Temp	deg C	Float	RA 2
14	RA 2 Receiver 1 Temp	deg C	Float	RA 2
15	RA 2 Receiver 2 Temp	deg C	Float	RA 2
16	RA 2 DFB Temp	deg C	Float	RA 2
17	Co-Latitude	deg (0-180)	Float	S/C
18	UTC	seconds	Float	POC

Note: 1) The composite receiver temperature is the temperature of the active RA receiver.

4.2 Payload Engineering Data File Format

The Engineering Data File Format follows:

<Frame Number:>

<AEFF> <RA Config> <WVR Config>

<Composite Receiver Temp>

<RA 1 TRS 1 Temp> <RA 1 TRS 2 Temp> <RA 1 Rcvr 1 Temp> <RA 1 Rcvr 2 Temp> <RA 1 DFB Temp>

<RA 2 TRS 1 Temp> <RA 2 TRS 2 Temp> <RA 2 Rcvr 1 Temp> <RA 2 Rcvr 2 Temp> <RA 2 DFB Temp>

<Co-Latitude>

<UTC>

Return to the [beginning](#)